HB 412 PRODUCT DESCRIPTION SHEET

GB IE



1. Rapid hotplate Ø 180 - 2000 W
2. Normal hotplate Ø 145 - 1000 W
3. Normal hotplate Ø 180 - 1500 W
4. Normal hotplate Ø 145 - 1000 W
5. Rapid hotplate control knob Ø 180
6. Normal hotplate control knob Ø 145
7. Normal hotplate control knob Ø 180
8. Normal hotplate control knob Ø 145
9. Hotplate operation control lamp

Operation of electric hotplates

- Set the knob to one of position 1-6, which correspond to different temperatures.
- To switch off the hotplate, set the knob to position “0”.

DIMENSIONS OF COOKTOP AND WORKTOP (mm)





SUPPLY VOLTAGE	CONDUCTORS: NUMBER AND SIZE	ELECTRICAL CONNECTION
230 V ~ + ⏚	3 x 2.5 mm ^{2}	1 2 3 ⏚ L N